

Comfort series 4 mm not embeddable



CE

General specifications	
Switching element function	NAMUB NO
Rated operating distance s _n	4 mm
Installation	not embeddable
Assured operating distance s _a	0 2.88 mm
Nominal ratings	
Nominal voltage U_0	8 V
Operating voltage U _B	712 V
Switching frequency f	0 1 Hz
Current consumption	
Measuring plate not detected	≤ 1 mA
Measuring plate detected	≥ 2.4 mA
Standard conformity	
EMC in accordance with	IEC / EN 60947-5-2:1999
Standards	DIN EN 60947-5-6 (NAMUR)
Ambient conditions	
Ambient temperature	-25 70 °C (248 343 K)
Mechanical specifications	
Connection type	2 m, PVC cable
Core cross-section	0.34 mm ²
Housing material	PBT
Sensing face	PBT
Protection degree	IP68
General information	
Use in the hazardous area	see instruction manuals
Category	1G; 2G; 1D

Connection type:



Subject to reasonable modifications due to technical advances.

Copyright Pepperl+Fuchs, Printed in Germany

Capacitive proximity switches

ATEX 1G

Instruction

Device category 1G

Directive conformity Standard conformity

CE symbol

Ex-identification

EC-Type Examination Certificate Appropriate type Effective internal capacitance Ci Effective internal inductance Li Cable length

Explosion group IIA Explosion group IIB Explosion group IIC General

www.pepperl-fuchs.com Highest permissible ambient temperature

Installation, Comissioning

Maintenance

Special conditions Protection from mechanical danger

Electrostatic charging

Manual electrical apparatus for hazardous areas

for use in hazardous areas with gas, vapour and mist 94/9/EG EN 50014:1997: EN 50020:1994: EN 50284:1999 Ignition protection "Intrinsic safety' Use is restricted to the following stated conditions

€0102

⟨€x⟩ II 1G EEx ia IIC T6

TÜV 03 ATEX 2003 X CJ4-12GK-N... \leq 60 nF ; a cable length of 10 m is considered.

negligibly small

Dangerous electrostatic charges on the fixed connection cable must be taken into account for lengths equal to and exceeding the following values:

96 cm 48 cm

7 cm

The apparatus has to be operated according to the appropriate data in the data sheet and in this instruction manual.

The EU prototype test certificate must be observed. The special conditions must be adhered to! Directive 94/9EG and hence also the prototype test certificates are in general only applicable to the use of electrical apparatus operating at atmospheric conditions.

The use in ambient temperatures of > 60 °C was tested with regard to hot surfaces by the mentioned certification authority.

If the equipment is not used under atmospheric conditions, a reduction of the permissible minimum ignition energies may have to be taken into consideration.

The temperature ranges, according to temperature class, are given in the EU prototype test certificate. Note: Use the temperature table for category 1 !!! The 20 % reduction in accordance with EN 1127-1:1997 has already been accounted for in the temperature table for category 1.

Laws and/or regulations and standards governing the use or intended usage goal must be observed.

The intrinsic safety is only assured in connection with an appropriate related apparatus and according to the proof of intrinsic safety.

The associated apparatus must satisfy the requirements of category ia. Due to the possible danger of ignition, which can arise due to faults and/or transient currents in the equipotential bonding system, galvanic isolation of the power supply and signal circuit is preferable. Associated apparatus without electrical isolation must only be used if the appropriate requirements of IEC 60079-14 are met.

No changes can be made to apparatus, which are operated in hazardous areas. Repairs to these apparatus are not possible.

When used in the temperature range below -20°C the sensor should be protected from knocks by the provision of an additional housing

When used in group IIC non-permissible electrostatic charges should be avoided on the plastic housing parts.

Copyright Pepperl+Fuchs, Printed in Germany

2006-01-26 - 106262_ENG.xm

Capacitive proximity switches

ATEX 2G

Instruction

Device category 2G Directive conformity Standard conformity

CE symbol

Ex-identification EC-Type Examination Certificate Appropriate type Effective internal capacitance C_i Effective internal inductance L_i General

Highest permissible ambient temperature

Installation, Comissioning

Maintenance

Special conditions Protection from mechanical danger

Manual electrical apparatus for hazardous areas

for use in hazardous areas with gas, vapour and mist 94/9/EG EN 50014:1997, EN 50020:1994 Ignition protection "Intrinsic safety" Use is restricted to the following stated conditions

C€0102

⟨E⟩ II 1G EEx ia IIC T6
TÜV 03 ATEX 2003 X
CJ4-12GK-N...

 \leq 60 nF ; a cable length of 10 m is considered. negligibly small

The apparatus has to be operated according to the appropriate data in the data sheet and in this instruction manual. The EU prototype test certificate must be observed. The special conditions must be adhered to! Directive 94/9EG and hence also the prototype test certificates are in general only applicable to the use of electrical apparatus operating at atmospheric conditions. The use in ambient temperatures of > 60 °C was tested with regard to hot sur-

The use in ambient temperatures of > 60 °C was tested with regard to hot surfaces by the mentioned certification authority.

If the equipment is not used under atmospheric conditions, a reduction of the permissible minimum ignition energies may have to be taken into consideration. The temperature ranges, according to temperature class, are given in the EU

prototype test certificate. Laws and/or regulations and standards governing the use or intended usage

Laws and/or regulations and standards governing the use or intended usage goal must be observed.

 $\bar{T}he$ intrinsic safety is only assured in connection with an appropriate related apparatus and according to the proof of intrinsic safety.

No changes can be made to apparatus, which are operated in hazardous areas. Repairs to these apparatus are not possible.

When used in the temperature range below -20°C the sensor should be protected from knocks by the provision of an additional housing.

2006-01-26 - 106262_ENG.xml

Copyright Pepperl+Fuchs, Printed in Germany

Capacitive proximity switches

ATEX 1D

Instruction

Device category 1D Directive conformity

Standard conformity

CE symbol

Ex-identification

EC-Type Examination Certificate Appropriate type Effective internal capacitance C_i Effective internal inductance L_i General

Maximum housing surface temperature

Installation, Comissioning

Maintenance

[Fett]Special conditions Electrostatic charging

Manual electrical apparatus for hazardous areas

for use in hazardous areas with combustible dust 94/9/EG IEC 61241-11:2002: draft; prEN61241-0:2002 type of protection intrinsic safety "iD" Use is restricted to the following stated conditions €€0102

(x) II 1D Ex iaD 20 T 85 °C (358 K)

ZELM 03 ATEX 0128 X CJ4-12GK-N...

 \leq 60 nF ; a cable length of 10 m is considered. negligibly small

The apparatus has to be operated according to the appropriate data in the data sheet and in this instruction manual.

The EU prototype test certificate must be observed.

The special conditions must be adhered to!

The maximum surface temperature of the housing is given in the EC-Type Examination Certificate.

Laws and/or regulations and standards governing the use or intended usage goal must be observed.

The intrinsic safety is only assured in connection with an appropriate related apparatus and according to the proof of intrinsic safety.

The associated apparatus must satisfy at least the requirements of category ia IIB or iaD. Because of the possibility of the danger of ignition, which can arise due to faults and/or transient currents in the equipotential bonding system, galvanic isolation in the power supply and signal circuits is preferable. Associated apparatus without electrical isolation must only be used if the appropriate requirements of IEC 60079-14 are met.

The intrinsically safe circuit has to be protected against influences due to lightning.

When used in the isolating wall between Zone 20 and Zone 21 or Zone 21 und Zone 22 the sensor must not be exposed to any mechanical danger and must be sealed in such a way, that the protective function of the isolating wall is not impaired. The applicable directives and standards must be observed.

No changes can be made to apparatus, which are operated in hazardous areas. Repairs to these apparatus are not possible.

The connection cables are to be laid in accordance with EN 50281-1-2 and must not normally be subjected to chaffing during use.

Copyright Pepperl+Fuchs, Printed in Germany

2006-01-26 - 106262_ENG.xm