

CE 0102


# **Model Number**

NJ4-12GK-SN

## Features

- 4 mm not embeddable ٠
- Usable up to SIL3 acc. to IEC61508 •





## Accessories

**BF 12** Mounting flange


# EXG-12

Mounting aid

Subject to modifications without notice Pepperl+Fuchs Group www.pepperl-fuchs.com

USA: +1 330 486 0001 fa-info@us.pepperl-fuchs.com





NJ4-12GK-SN

**General specifications** Switching element function Rated operatin Installation

**Technical Data** 

Dimensions

Switching element function		NAMUR NC
Rated operating distance	s <sub>n</sub>	4 mm
Installation		not embeddable
Output polarity		Safety Function
Assured operating distance	sa	0 3.24 mm
Reduction factor r <sub>Al</sub>		0.4
Reduction factor r <sub>Cu</sub>		0.3
Reduction factor r <sub>V2A</sub>		0.85
Nominal ratings		
Nominal voltage	Uo	8 V
Switching frequency	f	0 1500 Hz
Current consumption		
Measuring plate not detected		≥ 3 mA
Measuring plate detected		≤ 1 mA
Standard conformity		
EMC in accordance with		IEC / EN 60947-5-2:2004
Standards		DIN EN 60947-5-6 (NAMUR) VDE 660 Part 209
Ambient conditions		
Ambient temperature		-50 100 °C (223 373 K)
Mechanical specifications		
Connection type		2 m, silicone cable
Core cross-section		0.34 mm <sup>2</sup>
Housing material		PP
Sensing face		PP
Protection degree		IP68
Note		Security relevant only up to -40°C
General information		
Use in the hazardous area		see instruction manuals
Category		1G; 2G; 3G; 1D; 3D

ATEX 1G	
Instruction	Manual electrical apparatus for hazardous areas
Device category 1G	
	for use in hazardous areas with gas, vapour and mist
Directive conformity	94/9/EG
Standard conformity	EN 60079-0:2004, EN 60079-11:2007, EN 60079-26:2004 Ignition protection "Intrinsic safety" Use is restricted to the following stated conditions
CE symbol	€€0102
Ex-identification	⟨ы⟩ II 1G EEx ia IIC T6
EC-Type Examination Certificate	PTB 00 ATEX 2049 X
Appropriate type	NJ 4-12GK-SN
Effective internal capacitance C <sub>i</sub>	$\leq$ 70 nF ; a cable length of 10 m is considered.
Effective internal inductance Li	$\leq$ 150 $\mu H$ ; a cable length of 10 m is considered.
Cable length	Dangerous electrostatic charges on the fixed connection cable must be taken into account for lengths equal to and exceeding the following values:
Explosion group IIA	96 cm
Explosion group IIB	48 cm
Explosion group IIC	7 cm
General	The apparatus has to be operated according to the appropriate data in the data sheet and in this instruction manual. The EC-Type Examination Certificate has to be observed. The special conditions must be adhered to!
Highest permissible ambient temperature	The temperature ranges, according to temperature class, are given in the EC- Type Examination Certificate. Note: Use the temperature table for category 1 !!! The 20 % reduction in accordance with EN 1127-1 has already been applied to the temperature table for category 1.
Installation, Comissioning	Laws and/or regulations and standards governing the use or intended usage goal must be observed. The intrinsic safety is only assured in connection with an appropriate related apparatus and according to the proof of intrinsic safety. The associated apparatus must satisfy the requirements of category ia. Due to the possible danger of ignition, which can arise due to faults and/or tran- sient currents in the equipotential bonding system, galvanic isolation of the power supply and signal circuit is preferable. Associated apparatus without elec- trical isolation must only be used if the appropriate requirements of IEC 60079- 14 are met.
Maintenance	No changes can be made to apparatus, which are operated in hazardous areas. Repairs to these apparatus are not possible.
Special conditions	
Protection from mechanical danger	When used in the temperature range below -20 °C the sensor should be protec- ted from knocks by the provision of an additional bausing

When used in the temperature range below -20  $^\circ\text{C}$  the sensor should be protected from knocks by the provision of an additional housing.

Germany: +49 621 776-4411 fa-info@de.pepperl-fuchs.com

Copyright Pepperl+Fuchs Singapore: +65 6779 9091 fa-info@sg.pepperl-fuchs.com



ATEX 2G

Instruction

Device category 2G Directive conformity Standard conformity

CE symbol

Ex-identification

EC-Type Examination Certificate Appropriate type Effective internal capacitance C<sub>i</sub> Effective internal inductance L<sub>i</sub> General

Highest permissible ambient temperature

Installation, Comissioning

Maintenance

Special conditions Protection from mechanical danger Manual electrical apparatus for hazardous areas

for use in hazardous areas with gas, vapour and mist 94/9/EG EN 60079-0:2004, EN 60079-11:2007 Ignition protection "Intrinsic safety" Use is restricted to the following stated conditions  $C\in$ 0102

⟨€x⟩ II 1G EEx ia IIC T6

PTB 00 ATEX 2049 X NJ 4-12GK-SN...

 $\leq$  70 nF ; a cable length of 10 m is considered.

 $\leq$  150  $\mu H$  ; a cable length of 10 m is considered.

The apparatus has to be operated according to the appropriate data in the data sheet and in this instruction manual. The EC-Type Examination Certificate has to be observed. The special conditions must be adhered to!

The temperature ranges, according to temperature class, are given in the EC-Type Examination Certificate.

Laws and/or regulations and standards governing the use or intended usage goal must be observed. The intrinsic safety is only assured in connection with an appropriate related apparatus and according to the proof of intrinsic safety.

No changes can be made to apparatus, which are operated in hazardous areas. Repairs to these apparatus are not possible.

When used in the temperature range below -20 °C the sensor should be protected from knocks by the provision of an additional housing.



### ATEX 1D Instruction

### **Device category 1D** Directive conformity

Standard conformity

CE symbol

Ex-identification

EC-Type Examination Certificate Appropriate type Effective internal capacitance C<sub>i</sub> Effective internal inductance Li General

Maximum housing surface temperature

Installation, Comissioning

Maintenance

Special conditions Electrostatic charging for use in hazardous areas with combustible dust 94/9/EG IEC 61241-11:2002: draft; prEN61241-0:2002 type of protection intrinsic safety "iD" Use is restricted to the following stated conditions €0102

 $\textcircled{\mbox{(sc)}}$  II 1D Ex iaD 20 T 108  $^{\circ}\mbox{C}$  The Ex-significant identification is on the enclosed adhesive label

ZELM 03 ATEX 0128 X NJ 4-12GK-SN..

 $\leq$  70 nF ; a cable length of 10 m is considered.

 $\leq$  150  $\mu H$  ; a cable length of 10 m is considered.

The apparatus has to be operated according to the appropriate data in the data sheet and in this instruction manual.

NJ4-12GK-SN

The EC-Type Examination Certificate has to be observed. The special conditions must be adhered to!

The maximum surface temperature of the housing is given in the EC-Type Examination Certificate

Laws and/or regulations and standards governing the use or intended usage goal must be observed.

The intrinsic safety is only assured in connection with an appropriate related apparatus and according to the proof of intrinsic safety.

The associated apparatus must satisfy at least the requirements of category ia IB or iaD. Because of the possibility of the danger of ignition, which can arise due to faults and/or transient currents in the equipotential bonding system, galvanic isolation in the power supply and signal circuits is preferable. Associated apparatus without electrical isolation must only be used if the appropriate requirements of IEC 60079-14 are met. The intrinsically safe circuit has to be protected against influences due to lightning.

The adhesive label provided must be affixed in the immediate vicinity of the sensor! The surface to which the label is applied must be clean, flat and free from grease!

The affixed adhesive label must be readable and durable, taking account of the possibility of chemical corrosion!

When used in the isolating wall between Zone 20 and Zone 21 or Zone 21 und Zone 22 the sensor must not be exposed to any mechanical danger and must be sealed in such a way, that the protective function of the isolating wall is not impaired. The applicable directives and standards must be observed.

No changes can be made to apparatus, which are operated in hazardous areas. Repairs to these apparatus are not possible.

The connection cables are to be laid in accordance with EN 50281-1-2 and must not normally be subjected to chaffing during use.

Germany: +49 621 776-4411 fa-info@de.pepperl-fuchs.com



ATEX 3D	
Note	This instruction is only valid for products according to EN 50281-1-1, valid until 30-September-2008 Note the ex-marking on the sensor or on the enclosed adhesive label
Instruction	Manual electrical apparatus for hazardous areas
Device category 3D	for use in hazardous areas with non-conducting combustible dust
Directive conformity	94/9/EG
Standard conformity	EN 50281-1-1 Protection via housing Use is restricted to the following stated conditions
CE symbol	€€0102
Ex-identification	↔ II 3D IP68 T 111 °C X The Ex-significant identification is on the enclosed adhesive label
General	The apparatus has to be operated according to the appropriate data in the data sheet and in this instruction manual. The data stated in the data sheet are restricted by this operating instruction! The special conditions must be adhered to!
Installation, Comissioning	Laws and/or regulations and standards governing the use or intended usage goal must be observed. The adhesive label provided must be affixed in the immediate vicinity of the sensor! The surface to which the label is applied must be clean, flat and free from grease! The affixed adhesive label must be readable and durable, taking account of the possibility of chemical corrosion!
Maintenance	No changes can be made to apparatus, which are operated in hazardous areas. Repairs to these apparatus are not possible.
Special conditions	
Minimum series resistance $R_V$	A minimum series resistance RV is to be provided between the power supply voltage and the proximity switch in accor- dance with the following list. This can also be assured by using a switch amplifier.
Maximum operating voltage UBmax	The maximum permissible operating voltage UBmax must be restricted to the values given in the following list. Toleran- ces are not permitted.
Maximum heating (Temperature rise)	Values can be obtained from the following list, depending on the max. operating voltage Ub max and the minimum series resistance Rv.
at U <sub>Bmax</sub> =9 V, R <sub>V</sub> =562 $\Omega$	11 °C
using an amplifier in accordance wit EN 60947-5-6	h 11 °C
Protection from mechanical danger	The sensor must not be mechanically damaged.
Protection of the connection cable	The connection cable must be prevented from being subjected to tension and torsional loading.



ATEX 3D (tD)	
Note	This instruction is only valid for products according to EN 61241-0:2006 and EN 61241-1:2004 Note the ex-marking on the sensor or on the enclosed adhesive label
Instruction	Manual electrical apparatus for hazardous areas
Device category 3D	for use in hazardous areas with non-conducting combustible dust
Directive conformity	94/9/EG
Standard conformity	EN 61241-0:2006, EN 61241-1:2004 Protection via housing "tD" Use is restricted to the following stated conditions
CE symbol	CE
Ex-identification	II 3D Ex tD A22 IP67 T80°C X The Ex-relevant identification may also be printed on the accompanying adhesive label.
General	The apparatus has to be operated according to the appropriate data in the data sheet and in this instruction manual. The maximum surface temperature has been determined in accordance with method A without a dust layer on the equipment. The data stated in the data sheet are restricted by this operating instruction! The special conditions must be adhered to!
Installation, Comissioning	Laws and/or regulations and standards governing the use or intended usage goal must be observed. The adhesive label provided must be affixed in the immediate vicinity of the sensor! The surface to which the label is applied must be clean, flat and free from grease! The affixed adhesive label must be readable and durable, taking account of the possibility of chemical corrosion!
Maintenance	No changes can be made to apparatus, which are operated in hazardous areas. Repairs to these apparatus are not possible.
Special conditions	
Minimum series resistance $R_V$	A minimum series resistance RV is to be provided between the power supply voltage and the proximity switch in accor- dance with the following list. This can also be assured by using a switch amplifier.
Maximum operating voltage UBmax	The maximum permissible operating voltage UBmax must be restricted to the values given in the following list. Toleran- ces are not permitted.
Maximum permissible ambient temper ture	a-Values can be obtained from the following list, depending on the max. operating voltage Ub max and the minimum series resistance Rv.
at U <sub>Bmax</sub> =9 V, R <sub>V</sub> =562 $\Omega$ using an amplifier in accordance wi EN 60947-5-6	58 °C th 58 °C
Protection from mechanical danger	The sensor must not be exposed to ANY FORM of mechanical danger.
Protection from UV light	The sensor and the connection cable must be protected from damaging UV-radiation. This can be achieved when the sensor is used in internal areas.
Protection of the connection cable	The connection cable must be prevented from being subjected to tension and torsional loading.

Release date: 2008-09-30 12:19 Date of issue: 2008-10-08 106641\_ENG.xml

6



ATEX 3G (nL) Instruction	Manual electrical apparatus for hazardous areas
Device category 3G (nL)	for use in hazardous areas with gas, vapour and mist
Directive conformity	94/9/EG
Standard conformity	EN 60079-15:2005 Ignition protection category "n" Use is restricted to the following stated conditions
CE symbol	<b>C€</b> 0102
Ex-identification	$\bigotimes$ II 3G Ex nL IIC T6 X The Ex-significant identification is on the enclosed adhesive label
Effective internal capacitance C <sub>i</sub>	$\leq$ 70 nF ; a cable length of 10 m is considered.
Effective internal inductance L <sub>i</sub>	$\leq$ 150 $\mu H$ ; A cable length of 10 m is considered.
General	The apparatus has to be operated according to the appropriate data in the data sheet and in this instruction manual. The data stated in the data sheet are rest- ricted by this operating instruction! The special conditions must be observed! Directive 94/9EG is generally applicable only to the use of electrical apparatus operating at atmospheric conditions. If the equipment is not used under atmospheric conditions, a reduction of the permissible minimum ignition energies may have to be taken into consideration
Installation, Comissioning	Laws and/or regulations and standards governing the use or intended usage goal must be observed. The sensor must only be operated with energy-limited circuits, which satisfy the requirements of IEC 60079-15. The explosion group depends on the connected and energy-limited supply circuit. The adhesive label provided must be affixed in the immediate vicinity of the sensor! The surface to which the label is applied must be clean, flat and free from grease! The affixed adhesive label must be readable and durable, taking account of the possibility of chemical corrosion!
Maintenance	No changes can be made to apparatus, which are operated in hazardous areas Repairs to these apparatus are not possible.
Special conditions	
Maximum permissible ambient temperature T <sub>Umax</sub> at Ui = 20 V	
for Pi=34 mW, li=25 mA, T6	55 °C
for Pi=34 mW, li=25 mA, T5	55 °C
for Pi=34 mW, li=25 mA, T4-T1	55 °C
for Pi=64 mW, li=25 mA, T6	55 °C
for Pi=64 mW, li=25 mA, T5	55 °C
for Pi=64 mW, li=25 mA, T4-T1	55 °C
for Pi=169 mW, li=52 mA, T6	41 °C
for Pi=169 mW, li=52 mA, T5	41 °C
for Pi=169 mW, li=52 mA, T4-T1	41 °C
for Pi=242 mW, li=76 mA, T6	29 °C
for Pi=242 mW, li=76 mA, T5	29 °C
for Pi=242 mW, li=76 mA, T4-T1	29 °C
Protection from mechanical danger	The sensor must not be exposed to <b>ANY FORM</b> of mechanical danger. When used in the temperature range below -20 °C the sensor should be protected from knocks by the provision of an additional housing.
Protection from UV light	The sensor and the connection cable must be protected from damaging UV- radiation. This can be achieved when the sensor is used in internal areas.
Protection of the connection cable	The connection cable must be prevented from being subjected to tension and torsional loading.
Connection parts	The connection parts are to be installed, such that a minimum protection class of IP20 is achieved in accordance with IEC 60529

The connection parts are to be installed, such that a minimum protection class of IP20 is achieved, in accordance with IEC 60529.

 Subject to modifications without notice

 Pepperl+Fuchs Group
 US

 www.pepperl-fuchs.com
 fa-info

USA: +1 330 486 0001 fa-info@us.pepperl-fuchs.com

Germany: +49 621 776-4411 fa-info@de.pepperl-fuchs.com

Copyright Pepperl+Fuchs Singapore: +65 6779 9091 fa-info@sg.pepperl-fuchs.com



7

ATEX 3G (ic)	
Instruction	Manual electrical apparatus for hazardous areas
Device category 3G (ic)	for use in hazardous areas with gas, vapour and mist
Directive conformity	94/9/EG
Standard conformity	EN 60079-11:2007 Ignition protection category "ic"
	Use is restricted to the following stated conditions
CE symbol	(€
Ex-identification	⟨€x⟩ II 3G Ex ic IIC T6 X The Ex-significant identification is on the enclosed adhe-
Ex-Identification	sive label
Effective internal capacitance C <sub>i</sub>	$\leq$ 70 nF ; a cable length of 10 m is considered.
Effective internal inductance L <sub>i</sub>	$\leq$ 150 µH ; A cable length of 10 m is considered.
·	
General	The apparatus has to be operated according to the appropriate data in the data
	sheet and in this instruction manual. The data stated in the data sheet are rest- ricted by this operating instruction!
	The special conditions must be observed!
	Directive 94/9EG is generally applicable only to the use of electrical apparatus operating at atmospheric conditions.
	If the equipment is not used under atmospheric conditions, a reduction of the
	permissible minimum ignition energies may have to be taken into consideration.
Installation, Comissioning	Laws and/or regulations and standards governing the use or intended usage
	goal must be observed. The sensor must only be operated with energy-limited circuits, which satisfy the requirements of IEC 60079-11. The explosion group
	depends on the connected and energy-limited supply circuit.
	The adhesive label provided must be affixed in the immediate vicinity of the sen- sor! The surface to which the label is applied must be clean, flat and free from
	grease!
	The affixed adhesive label must be readable and durable, taking account of the
Maintenance	possibility of chemical corrosion!
Maintenance	No changes can be made to apparatus, which are operated in hazardous areas. Repairs to these apparatus are not possible.
[Fett]Special conditions	
Maximum permissible ambient temperature $T_{Umax}$ at Ui = 20 V	
for Pi=34 mW, li=25 mA, T6	55 °C
for Pi=34 mW, li=25 mA, T5	55 °C
for Pi=34 mW, li=25 mA, T4-T1	55 °C
for Pi=64 mW, li=25 mA, T6	55 °C
for Pi=64 mW, li=25 mA, T5	55 °C
for Pi=64 mW, li=25 mA, T4-T1	55 °C
for Pi=169 mW, li=52 mA, T6	41 °C
for Pi=169 mW, li=52 mA, T5	41 °C
for Pi=169 mW, li=52 mA, T4-T1	41 °C
for Pi=242 mW, li=76 mA, T6	29 °C
for Pi=242 mW, li=76 mA, T5	29 °C
for Pi=242 mW, li=76 mA, T4-T1	29 °C
Protection from mechanical danger	The sensor must not be mechanically damaged.
	When used in the temperature range below -20 °C the sensor should be protec- ted from knocks by the provision of an additional housing.
	- · · · · · · · · · · · · · · · · · · ·

Connection parts

# The connection parts are to be installed, such that a minimum protection class of IP20 is achieved, in accordance with IEC 60529.

Germany: +49 621 776-4411 fa-info@de.pepperl-fuchs.com

Copyright Pepperl+Fuchs Singapore: +65 6779 9091 fa-info@sg.pepperl-fuchs.com

