

 ϵ

Order Code


UB400-12GM-I-V1

Features

- Analogue output 4 mA ... 20 mA
- · Measuring window adjustable
- TEACH-IN input
- Temperature compensation


Electrical Connection

Standard symbol/Connections: (version I)



Core colours in accordance with EN 60947-5-2.

Dimensions



Technical Data

General specifications	
Sensing range	30 400 mm
Adjustment range	50 400 mm
Unusable area	0 30 mm
Standard target plate	100 mm x 100 mm
Transducer frequency	approx. 310 kHz
Response delay	approx. 50 ms
Indicators/operating means	

LED yellow

permanently yellow: object in the evaluation range yellow, flashing: TEACH-IN function, object detected LED red permanently red: Error red, flashing: TEACH-IN function, object not detected

Electrical specifications Operating voltage

10 ... 30 V DC , ripple 10 %SS

No-load supply current I₀ ≤ 30 mA Input

Input type 1 TEACH-IN input

lower evaluation limit A1: -U_B ... +1 V, upper evaluation limit A2: +4 V ... +U_B

input impedance: > 4.7 k Ω , pulse duration: \geq 1 s

Output 1 analogue output 4 ... 20 mA, short-circuit/overload protected Output type Resolution 0.17 mm

Deviation of the characteristic ± 1 % of full-scale value curve

± 0.5 % of full-scale value Repeat accuracy Load impedance 0 ... 300 Ω at U_B > 10 V; 0 ... 500 &Omega at $U_B > 15 \text{ V}$ ± 1.5 % of full-scale value

Temperature influence Standard conformity Standards EN 60947-5-2

Ambient conditions -25 ... 70 °C (248 ... 343 K) Ambient temperature Storage temperature -40 ... 85 °C (233 ... 358 K)

Mechanical specifications Protection degree IP65

Connection Material V1 connector (M12 x 1), 4-pin

Housing brass, nickel-plated

epoxy resin/hollow glass sphere mixture; foam polyurethane, cover PBT 25 g Transduce

Connector V1



120342_ENG.xml

Adjusting the evaluation limits

The ultrasonic sensor features an analogue output with two teachable evaluation limits. These are set by applying the supply voltage -U_B or +U_B to the TEACH-IN input. The supply voltage must be applied to the TEACH-IN input for at least 1 s. LEDs indicate whether the sensor has recognised the target during the TEACH-IN procedure. The lower evaluation limit A1 is taught with -U_B, A2 with +U_B.

Two different output functions can be set:

- 1. Analogue value increases with rising distance to object (rising ramp)
- 2. Analogue value falls with rising distance to object (falling ramp)

TEACH-IN rising ramp (A2 > A1)

- Position object at lower evaluation limit
- TEACH-IN lower limit A1 with U_B
- Position object at upper evaluation limit
- TEACH-IN upper limit A2 with + UB

TEACH-IN falling ramp (A1 > A2):

- Position object at lower evaluation limit
- TEACH-IN lower limit A2 with + U_R
- Position object at upper evaluation limit
- TEACH-IN upper limit A1 with UR

Default setting

A1: unusable area

nominal sensing range

Mode of operation: rising ramp

LED Displays


Displays in dependence on operating mode	Red LED	Yellow LED
TEACH-IN evaluation limit		
Object detected	off	flashes
No object detected	flashes	off
Object uncertain (TEACH-IN invalid)	on	off
Normal mode (evaluation range)	off	on
Fault	on	previous state

Installation conditions

If the sensor is installed at places, where the environment temperature can fall below 0 °C, for the sensors fixation, one of the mounting flanges BF 12, BF 12-F or BF 5-30 must be used. In case of direct mounting of the sensor in a through hole, it has to be fixed at the middle of the housing thread.


Characteristic Curves/Additional Information

Characteristic response curve



Curve 1: flat surface 100 mm x 100 mm Curve 2: round bar, Ø 25 mm

Programmed analogue output function



Accessories

UB-PROG2 Programming unit

BF 5-30 Mounting flange

BF 12 Mounting flange

BF 12-F Mounting flange

V1-G-2M-PVC Cable connector

V1-W-2M-PUR Cable connector

UVW90-M12 Deviation reflector